



Rev. 1020

StowAway MAX Lid Rack Instructions (020.41)

Parts Included:

- 1 - Lid Rack Assembly
- 4 - Large Rubber Washers
- 4 - Phillips Screws
- 4 - Metal Washers
- 4 - Nylock Nuts
- 8 - Small Rubber Washers

Tools Needed:

- Drill & 1/4" drill bit
- Phillips Screwdriver
- Tape Measure
- 7/16" wrench

The lid rack is designed for 15 lbs. of gear. Overloading may cause the lid to bow.

www.StowAway2.com

800-943-5377

StowAway Max Lid Rack Installation:

Drilling

1. Center and position the rack on the lid, oriented as shown. The front corner of lid rack should measure about 11.5" from the front edge of the lid.
2. Holding the rack firmly in place, push a small screwdriver or nail through the right front bracket mounting hole and mark the lid for drilling. Remove the lid rack and drill a $\frac{1}{4}$ " hole in the lid where marked.
3. Reposition the rack on the lid, drop the mounting screw through the bracket and lid. On the opposite side of the lid rack, holding the rack firmly, mark a second mounting hole and drill the lid. Insert a second screw through the bracket and lid. Check the position of the lid and mark and drill the remaining two lid rack holes.

Assembly

1. Position the rack over the lid rack holes, add a small rubber washer to each screw and drop the screws through the bracket. Add a second small rubber washer to each screw between the bracket and the lid and insert the screws through the lid. Complete for all 4 mounting screws.
2. Holding the rack in place, open lid and place a large rubber washer, metal washer, and a nylock nut onto each screw. Tighten the nuts until the lid rack is snug to the lid. Note that the screws may initially seem too short but as they are started and tightened the rubber washers will compress allowing proper tightening of the nut.

