



Wire Harness Replacement Instructions for the Stowaway Carrier REV0516.1

Tools required:

- Philips screwdriver.

Removal Instructions:

- Before removing existing wire harness, take a moment to view how the existing harness is installed.
- Release the existing harness by unplugging the harness ends from the taillights and removing the wire harness guides. Save the guides and screws for reuse.
- Pull the old harness through the wire harness hole from outside the box, one side at a time.

Installation Instructions:

1. Feed the new harness through the wire harness hole from outside the box, one side at a time.
2. Once the harness is inside the box route the wires to the driver's side and passenger side taillights, the longer side of the harness to the driver's side, the shorter side of the harness to the passenger side.
3. Partially insert the wire guide screws back into the guide screw holes.
4. Starting at the back of the box, lift the wire up under the internal lip of the box, just under one of the wire guide screws. Lift one wire guide into position under a screw, lay the harness into the guide and tighten the screw into the guide. Repeat with the other wire guides as you move from the back to the front of the box, pulling the slack out of the wire as you go along.
5. Continue with the remaining wire guides and screws.
6. Plug taillights into the newly installed wiring harness and test all taillight functions.

If you encounter any problems while installing the new wire harness or have any questions regarding the installation, please call customer service at 1-800-943-5377.