



StowAway2

Cargo Carriers



Assembly Instructions

StowAway SwingAway Frame
Part # ST 022.9, 022.91, 022.92
(Rev. 0218)



Please review the instructions and safety guidelines carefully before assembling the StowAway Swingaway Frame. Assembly and installation of the frame are solely the end user's responsibility.

See www.StowAway2.com for more information and videos about assembling the Swingaway Frame.

StowAway Warnings and Guidelines

- **EXHAUST WARNING** – Hot exhaust directed at or below the Swingaway frame could melt or damage items that you have mounted to the frame. For vehicles with straight back exhaust it is recommended that the exhaust be diverted with an exhaust pipe tip or deflected away from your contents with an exhaust shield. Exhaust shields are not necessary on vehicles with tail pipes that direct the exhaust downward or to the side of your contents.
- The Swingaway Frame is not intended for off-road use.
- Swingaway models designed for a 2" hitch receiver should be used with a Class III or IV 2" receiver hitch. Swingaway models designed for a 1.25" hitch receiver should be used with a Class II, 1.25" hitch receiver. We do not recommend the use of a 1.25" to 2" hitch converter with the Swingaway frame under any conditions. A seven inch hitch extender can be used with Class III or IV hitches rated for more than 500 pounds tongue weight. Under no circumstances should the hitch tongue weight, vehicle tongue weight, or the vehicle gross vehicle weight be exceeded.
- Before driving, be sure that the SwingAway frame is latched and both safeties are engaged. The frame should be regularly inspected for signs of wear, corrosion and/or fatigue.
- Rinse and lightly oil the Swingaway frame and hardware after traveling on salted roads or when using the frame in a salt air environment. Coating the inside and outside of the frame with a rust preventive product is advised in the case of regular exposure to salt or salt air.




StowAway²

Cargo Carriers


SwingAway Frame

1. Swing Arm
2. Bent Hitch bar



Hardware Kit

- 1 - 3/4" Pivot Bolt
- 4 - Flat Washers for Pivot Bolt
- 1 - 3/4" Nylok Lock Nut for Pivot Bolt
- 1 - Hitch Pin (Not included if hitch lock is ordered)
- 1 - Hitch Tightener



Tools Required for Assembly

Two large adjustable end wrenches or socket wrenches with 9/16" and 1 1/8" sockets.

StowAway2

Cargo Carriers

1. Assembling the Frame

- Slide the Bent Hitch Bar into your vehicle's trailer hitch until the hitch pin holes are aligned (Fig 1). Locate the Hitch Pin or Hitch Lock from the hardware kit and insert the pin into the hitch. The hitch tightener need not be installed at this time unless you plan to use the Swingaway frame immediately.
- Fit the swing arm yoke over the point of rotation on the hitch bar (Fig 2). Position two pivot bolt washers (Fig 3), one on top of the yoke and one between the yoke and bar, then insert the pivot bolt through the yoke and the hitch bar. Insert the third washer the yoke and bar (grease washer and tap into place if it is tight) before pushing the pivot bolt through the bottom of the yoke. Add the fourth washer to the end of the pivot bolt after the bolt is all the way through. Hand tighten the nylok lock nut onto the pivot bolt until you feel resistance, then with two large wrenches, tighten the nut all the way to the bottom of the yoke. Note, it is normal for the nylok to require firm pressure when being tightened.
- Test the frame to ensure that the Swing Arm swings freely.
- Close the swing arm until the plunger pin engages and holds the frame closed. The frame has been welded so that the spear comes in at or just above the latch hole when swung closed. If your spear comes in high, add your gear box or rack to the frame, load it, and swing it closed again. If necessary, push down firmly on the end of your gear box or rack when closing the frame. Once loaded and latched your frame will slowly conform to the closed position. For questions, watch the assembly video on our website.

Fig 1




Fig 2





Fig 3



StowAway²

Cargo Carriers

Using the Swingaway Frame

1. The SwingAway frame is equipped with a latch, a threaded safety and a secondary safety. To close the frame, swing it closed until the latch engages. Tighten the primary T-Bolt safety fully until the T-Bolt washer is flush to the frame. Be sure that the threads are properly aligned when tightening the bolt. Drop the secondary safety into place at the pivot point.
2. To open the frame remove both safeties, pull up on the orange plunger pin and swing the frame open.
3. The SwingAway frame may be locked at 90 degrees from the vehicle by inserting the secondary safety pin into hole at the pivot point. Care should be taken when swinging the frame open near traffic or on an incline. Your gear should be loaded with the frame in the closed position if possible.
4. The frame includes four holes for mounting a gear box or rack to the frame with 3/8" bolts, washers and nuts.



StowAway2

Cargo Carriers

Warranty on the Swingaway Frame

Pacific Recreational Products, Inc. (PRP) warrants to the original retail purchaser of the Swingaway frame that it is and shall remain free of defects in materials and workmanship for a period of ten years from the date of retail purchase. The limited warranty does not cover normal wear and tear, rust or corrosion, or damages caused by collision, disaster, abuse, modification or misuse. Misuse includes but is not limited to overloading of the carrier, exceeding the vehicle's load capacities, exceeding the hitch receiver's load capacities, improper installation, off-road use, use with a hitch of an incorrect size and style, damage to your gear from exhaust gas or and rust/corrosion caused by use.

This warranty does not cover rust or corrosion to the frame or hardware caused by moisture, salted roads or exposure to a salt air environment. To inhibit rust or corrosion caused by these factors, the frame and hardware should be rinsed clean after each use, dried thoroughly and all hardware coated with light oil or a rust inhibitor like Rustoleum.

Warranty services may be obtained by first calling, emailing or writing to PRP and describing the problem or perceived defect. PRP may request documentation to fully understand the nature of the problem or defect. If a defect or problem is confirmed, PRP will, at its sole discretion, replace, repair, or authorize the return of the cargo carrier to PRP for a full or partial refund. Returns must be made to the specified address, along with the proof of purchase date, using the original shipping container or equivalent. Unless otherwise authorized, return transportation charges must be prepaid by the purchaser.

All express and implied warranties for this product, including the warranties of merchantability and fitness for a particular purpose, are limited in duration to a period of ten years from the date of purchase and no warranties, whether expressed or implied, will apply after this period.

If this product is defective, the sole remedy shall be repair, replacement or refund as provided above. In no event will PRP or any of its officers, employees, or agents be liable to the purchaser for any damages, including incidental or consequential damages, arising out of the use of or inability to use the cargo carrier, even if PRP has been advised of the possibility of such damages, or for any claim by another party.

Consult our website StowAway2.com for assembly videos and other product information.

Pacific Recreational Products, Inc.
7291 SW Tech Center Drive • Tigard, OR 97223
Ph.: 800.943.5377 • Fax: 503.968.1433

StowAway2.com

E-mail: customerservice@StowAway2.com

Thank you for purchasing a StowAway Carrier product!

